

# Tivoli Mfg. Ltd.

Howfield Lane, Chartham, Canterbury, Kent, England  
Tel: (1227) 731156 Fax: (1227) 731137

---

## **Safety Bulletin**

**Bulletin No:** RMSA005  
**Ride Type:** Re-Mix II  
(aka. Extreme)  
**Date:** February 15, 2011

**Page:** 1 of 1  
**Rides Included:** Prior 2010  
**Pages:** 1  
**Parts supplied:** Yes

**Purpose: Saddle Horn Extension**

In order to reduce the space between the lap bar and the saddle horn on the ReMix II seat, Tivoli Mfg. Ltd. has developed a fiberglass extension cap to be installed over the existing saddle horn on all ReMix II rides in operation. This extension will remove the possibility of a leg passing between the lap bar and the saddle horn when the lap bar is in the secondary lock position.

Extension kits are available through Tivoli's USA Representative WorldRide Service & Supply Inc., by contacting 817-6412-5045 or email: [worldride@sbcglobal.net](mailto:worldride@sbcglobal.net) .

The horn extensions are installed by first applying a coating of general purpose epoxy to the top portion of the existing saddle horn. Apply a liberal amount of silicone adhesive around the base flange and screw holes. Push the extension over the existing horn and pilot drill all screw holes prior to installing 3 countersunk stainless steel screws in back and 3 pan head stainless steel screws in front. When the horn is screwed in place wipe excess silicone from flange.

Tivoli Mfg. Ltd.